


5 Carpenter Road
East Tamaki
PO Box 58-491, Botany
Manukau 2163, New Zealand
Telephone 064 09 274 5929
Facsimile 064 09 273 9509
Email info@sikatech.co.nz
Website www.sikatech.co.nz

Modular Aluminium Jointing Chamber 700 x 600 x 700 / 900H

ASSEMBLY INSTRUCTIONS

Chamber Rating: CLASS D - 210kN - AS3996:2006 Sika 'Chambers' are used for both Pathway & Roadway Installations



Chamber 700 x 600 x 700H



1. Place the **chamber base** on a flat area adjoining the pit or on a prepared bed of imported material in the excavated pit. Note the Sika logo will be face up.




Fig 1

2. Where there is existing ducting and minimal side excavation is required use a **split base**. Ref Fig 2





Fig 2

3. Remove the plastic tubes protecting the 4 – M10 studs protruding from the **chamber base** and place the two **chamber sides** into place.

Insert the two **chamber sides** into the appropriately marked positions on the **chamber base**. **Chamber side supports** cast into the **chamber base** will hold the **chamber sides** vertical until the 4 – M10 nuts and washers are applied to hold them down. (*Do not tighten these yet.*)



4. Add the two **chamber ends 600** and secure them with the 8 – M10 x 30 bolts and washers. (Now tighten all the aforementioned fixings.)




Fig 4

5. Apply the two polypropylene **duct entry panels** to each end recess and secure each one with 7 - M10 x 30 bolts and washers supplied.




Fig 5a





Fig 5b

Chamber 700 x 600 x 700H


Chamber Extension 200mm


6. Assemble **chamber extension** as per Fig. 6a using 8 - M10 x 30 bolts and washers supplied. Place on top of chamber flange. See arrows for right way up.





Chamber Accessories

Cable Support Options









Option 145 mm Long Option 250 mm Long

